Legendary Lighting, LLC INSTALLATION INSTRUCTIONS FOR E-Z Mount WSB (Wall Mount Support Bracket)



Mount the WSB at the desired location using the four (4) 1/4" x 1 1/2" bolts supplied. If mounting on brick, stone or stucco, masonry anchors or other mounting hardware may be needed. Legendary Lighting does not supply masonry anchors.



Position the light bracket on top of the WSB. Secure in place using one bolt through the far left or far right hole in the top of the lantern bracket and through the curved slot at the top of the WSB. Secure the bolt with nylock nut; make sure to leave the bolt and nut loose enough to be able to rotate or swivel the lantern bracket.



After connecting to gas and/or electricity, rotate the lantern bracket into final position and install one bolt at top center and one bolt at bottom right. If a top curl is



used, assemble it while installing the top center bolt.



For technical assistance, please call 1-800-350-5361.



Insert no. IW02006 Rev. 1 01/19/2009